

ProfiSignal versions

Modules and functions	Go	Basic	Klicks	Viewer
DataService / Configurator				
Data recording (database)	X	X	X	
Message device configuration	X	X	X	
Interface management	X	X	X	
User management and password protection	X	X	X	
Scheduler – programmable data transfer	X	X	X	
Calculation, integrator channels, monitoring channels	X	X	X	
Diagrams (on- and offline)				
y(t) diagram	X	X	X	X
Logic diagram for signal analysis	X	X	X	X
y(x) diagram	X	X	X	X
y(x) color diagram	X	X	X	X
Measurement data export - ASCII and CSV	X	X	X	X
Diagram as EMF export	X	X	X	X
Graphical elements				
Analog display		X	X	
Digital display		X	X	
LEDs		X	X	
Block display		X	X	

Background images and animated .gif files		X	X
Operating and control elements			
Buttons		X	X
Switches		X	X
Text input		X	X
Radio-Button		X	X
Dropdown boxes		X	X
Slide controls		X	X
Manual controls		X	X
Programming			
Test parameter management			X
Report programming			X
Process control and automation functions			X
Timer and event management			X
Table management			X
Adapter channels			X
Application variables			X
Application tables (2D and 3D)			X
Other functions			
Data recorder with trigger functions	X	X	X
Screen print out function		X	X
Set point curves		X	X
Date and time display		X	X
Offline calculation channels	X	X	X
Global alarm tables		X	X

Vibro option

FFT and cascade diagrams	X	X	X
--------------------------	---	---	---

Orbit diagram	X	X	X
---------------	---	---	---

AlarmManagement option

Configurable alarm table	X	X	X
--------------------------	---	---	---

Fault diagnostics	X	X	
-------------------	---	---	--